

WORLDE MIDI键盘控制器号设置教程

MIDI键盘型号EASYCONTROL 面板控制 初始控制器号

Editor

File Edit Communication Help

SCENE 1 SCENE 2 SCENE 3 SCENE 4

CC# 14 CC# 15 CC# 16 CC# 17 CC# 18 CC# 19 CC# 20 CC# 21 CC# 22

CC# 3 CC# 4 CC# 5 CC# 6 CC# 7 CC# 8 CC# 9 CC# 10 CC# 11

CC# 23 CC# 24 CC# 25 CC# 26 CC# 27 CC# 28 CC# 29 CC# 30 CC# 31

CC# 1 CC# 2

CC# 49 CC# 47 CC# 48 CC# 46 CC# 45 CC# 44

CC/Note Number

CONTROL

Mod Button - 2

Group Common - 1

Group Common - 2

Group Common - 3

Group Common - 4

Group Common - 5

Group Common - 6

Group Common - 7

Group Common - 8

Assign Type Control Change

CC Number 2

Button Behavior Momentary

On Value 127

Off Value 0



WORLDE MIDI键盘控制器号设置说明

1) WORLDE MIDI键盘支持所有通用MIDI格式的应用软件，如您在初次使用WORLDE MIDI键盘时遇到因控制器号不匹配而无法成功连接应用软件的问题，请参考本说明对应用软件的控制器号进行设置。如：WORLDE KS49A的SLIDER推杆的初始控制器号为147，若您欲将此SLIDER推杆和应用软件上的某个SLIDER推杆成功匹配，您需要先将应用软件上这个SLIDER推杆的控制器号设置为147。

2) 由于MIDI协议规定的控制器号范围为0到127，如需使初始控制器号超过127的面板控制与应用软件成功匹配，您需要先将此面板控制的控制器号更改为0到127之间的控制器号，然后使用和上述1同样的方式使此面板控制成功匹配应用软件。如：WORLDE KS49A的SLIDER推杆的初始控制器号为147，您需要先将此SLIDER推杆的控制器号更改为0到127之间的控制器号，然后再将应用软件上相对应的SLIDER推杆的控制器号更改为与此相同的控制器号即可。